

Application Instructions for Wheelie Bin Labels

Your labels: These are made of high quality sign-making vinyl that are easy to apply to your wheelie bin. Your labels are sandwiched between a backing sheet (printed grid lines) and an application sheet:

- Backing tape – printed grid lines
- Application tape – no grid lines

Fitting:

1. Ensure that the surface of the bin is clean and dust free.
2. Select position of the label and trace round the corners onto the surface of the bin in pencil to assist positioning.
3. Place the label face up (backing tape on the underside)
4. Rub the label text firmly working from the centre outwards with a credit card or the tips of your fingers. This will transfer the label from the backing tape to the surface of the application tape.
5. Turn the label over and **gently** peel off the backing tape. If any part of the label is not transferred to the application tape, re-seal the backing tape and rub the selected area again (step 4).
6. Once the backing tape has been removed position the label on to the surface of the bin pressing the application tape from the centre out.
7. Rub the application tape with a cloth to press the label onto the bin, working from the centre out to eliminate air bubbles and creases.
8. Leave the application tape attached to the label for 30 minutes.
9. After 30 minutes the application tape can be gently peeled away leaving the label in place.

With Compliments

We value your custom. All labels are supplied with a guarantee – simply return the damaged label for inspection and a full replacement will be dispatched free of charge.

Please recommend our product to family and friends using the enclosed leaflet.

Print-it Designs, PO Box 564,
Pinner, HA5 9FZ
United Kingdom
Tel: 07892 906 243
E-mail: sales@printitdesigns.com
www.printitdesigns.com